



SUBFLOOR LOWERING KIT



Quickly lower your subfloor for a low profile, curbless ADA, or barrier free shower

- One kit recesses up to 24 sq ft
- Perfect for I-joists or dimensional lumber because brackets attach to the top chord of joists and studs at parallel walls
- Wall brackets can be modified for different situations
- Achieves L/360 or better deflection rating with a live load of 40 PSF and dead load of 20 PSF

Subfloor Lowering Kit Includes:

- 15 Joist Brackets
- 6 Wall Brackets
- 81 Wood Screws
- 36 Joist Hanger Nails

Max Bracket Spacing 36" OC
2x4's, subflooring & subfloor adhesive not included



Visit our **YouTube** Channel
for installation videos
[youtube.com/hydroblok](https://www.youtube.com/hydroblok)

HYDROBLOK U.S.A. LLC
Suite 110 6029 238th St. SE
Woodinville, WA
USA 98072

TEL 425 286 6840
FAX 425 286 6854
sales@hydroblokusa.com



E116 3/4" FLOOR RECESS KIT

Covers approx. 24 sq ft



15 JOIST BRACKETS



Install with Included
1-5/8" Wood Screws



6 WALL BRACKETS



Install with Included
1-1/2" Wood Screws

INSTALLATION

1. Remove subfloor to walls and joists as needed. Sub-floor should not overhang the joist bay or be left unsupported.
2. Install joist and wall brackets. Brackets should be spaced a maximum of 36" on center to achieve L/360 with a live load of 40PSF and a dead load of 20PSF. Structural grade #2 or better douglas fir, larch or pine.
 - a. Use screws to attach joist brackets and joist hanger nails to attach wall brackets
 - b. Wall brackets can be bent onsite if needed (nail to subfloor or bottom plate then use hammer to bend the bracket down). Notches on wall bracket represent top and bottom of subfloor (see fig. 1).
3. Create 2x4 frame as shown and place frame into hangers. Best practice recommends subfloor adhesive and screws at hanger seats.
4. Install subfloor to 2x4 frame with adhesive and screws.




Fig. 1 Wall Bracket

